

Smart Series Facade Brush

Smart Series is the flexible choice for most common painting tasks. The brushes provide efficient paint pickup and even coverage, helping you achieve a solid and neat final result. Designed with a focus on ease of use, comfort, and easy cleaning. Ideal for both indoor and outdoor use when you want a good solution without paying for specialized features.



Product properties

Facade brush with durable bristles and angled ergonomic handle. Resilient bristles for high-viscosity products provide good coverage and a uniform finish. Suitable for treating uninterrupted surfaces. Can be mounted on a Flügger extension pole. Stainless steel ferrule prevents discoloration and ensures long service life.

- Versatile facade brush for everyday tasks
- Good balance between coverage and control
- Compatible with extension pole

Product use

Painting of facades and woodwork. Rinse the brush in water before use and work thoroughly into the paint. Store the brush in airtight packaging when not in use and avoid storing the brush in water.

Cleaning and Maintenance

Clean brushes with water, alternatively Brush cleaner, Basic cleaner or liquid soap. For non-aqueous paints, mineral turpentine can be used instead.

Useful Information

Disposal: Remove as much paint as possible from brushes before they are disposed of as small, combustible waste items.

Good practice

Remove as much paint as possible from tools before cleaning. Paint and cleaning fluid must not be poured down drains, but collected and disposed of as environmental waste. Clean the paint residue from the brushes right up under the ferrule. Paint residue under the ferrule and between fibres will coagulate and result in brittle bristles. Avoid loading the brushes during drying and store the brush dry.

Please note!

Use on very rough or textured surfaces may increase wear and shorten the brush's lifespan.

Country of Origin

Sweden

Technical Data

Shaft	Recycled plastic
Roller size	75 mm; 100 mm; 120 mm
Metal ring	Stainless steel ferrule

Current TDS Version

October 2026

Replaces TDS Version

May 2026